```
!pip -q install -U transformers datasets peft accelerate
import torch, transformers, datasets, peft, accelerate
print("Torch:", torch.__version__)
print("Transformers:", transformers.__version__)
```

Show hidden output

```
from dataclasses import dataclass
from typing import Optional
@dataclass
class TrainConfig:
    model_name: str = "facebook/opt-350m" # safer for Colab; change to opt-1.3b if GPU is strong
    train_path: str = "data/processed/train.jsonl"
    val_path: str = "data/processed/validation.jsonl"
    test_path: str = "data/processed/test.jsonl"
    output dir: str = "alpacare-lora"
    num_train_epochs: float = 1.0
    per_device_train_batch_size: int = 1
    per_device_eval_batch_size: int = 1
    gradient_accumulation_steps: int = 16
    learning rate: float = 2e-4
    warmup ratio: float = 0.03
    logging_steps: int = 50
    save_steps: int = 2000
    fp16: bool = True
    max_length: int = 512  # set 256 if 00M
    seed: int = 42
    max_train: Optional[int] = 5000
    max val: Optional[int] = 500
    max_test: Optional[int] = 500
cfg = TrainConfig()
cfg
TrainConfig(model_name='facebook/opt-350m', train_path='data/processed/train.jsonl', val_path='data/processed/validation.jsonl',
test_path='data/processed/test.jsonl', output_dir='alpacare-lora', num_train_epochs=1.0, per_device_train_batch_size=1,
per_device_eval_batch_size=1, gradient_accumulation_steps=16, learning_rate=0.0002, warmup_ratio=0.03, logging_steps=50,
save_steps=2000, fp16=True, max_length=512, seed=42, max_train=5000, max_val=500, max_test=500)
```

```
import os
from datasets import load_dataset, Dataset
def _standardize_record(rec):
    instr_keys = ["instruction", "question", "prompt"]
   out_keys = ["output","answer","response","target"]
    instruction = next((rec.get(k) for k in instr_keys if rec.get(k)), None)
              = next((rec.get(k) for k in out_keys if rec.get(k)), None)
    if not instruction or not output:
        return None
   return {"prompt": f"Instruction: {instruction}\n\nResponse:", "response": output}
def prepare_data_if_needed(cfg):
    if all(os.path.exists(p) for p in [cfg.train_path, cfg.val_path, cfg.test_path]):
        print("Found JSONL splits.")
        return
    raw = load_dataset("lavita/AlpaCare-MedInstruct-52k")
   base = raw["train"].map(_standardize_record).filter(lambda r: r["prompt"] is not None)
   dsd = base.train_test_split(test_size=0.05, seed=cfg.seed)
   train_full, test = dsd["train"], dsd["test"]
   val size = 0.05 / 0.95
    dsd_tv = train_full.train_test_split(test_size=val_size, seed=cfg.seed)
   train, val = dsd_tv["train"], dsd_tv["test"]
   train.to json(cfg.train path)
   val.to_json(cfg.val_path)
   test.to_json(cfg.test_path)
   print(" Saved JSONL splits.")
prepare_data_if_needed(cfg)
```

```
/usr/local/lib/python3.12/dist-packages/huggingface_hub/utils/_auth.py:94: UserWarning:
The secret `HF_TOKEN` does not exist in your Colab secrets.
To authenticate with the Hugging Face Hub, create a token in your settings tab (https://huggingface.co/settings/tokens), set it as
You will be able to reuse this secret in all of your notebooks.
Please note that authentication is recommended but still optional to access public models or datasets.
 warnings.warn(
README.md: 100%
                                                              944/944 [00:00<00:00, 69.2kB/s]
data/train-00000-of-00001-297892d5d4e8a0(...): 100%
                                                                                           36.7M/36.7M [00:01<00:00, 31.8MB/s]
                                                                     52002/52002 [00:00<00:00, 90505.08 examples/s]
Generating train split: 100%
Map: 100%
                                                       52002/52002 [00:06<00:00, 9003.58 examples/s]
Filter: 100%
                                                       52002/52002 [00:02<00:00, 17313.28 examples/s]
                                                                               47/47 [00:02<00:00, 18.98ba/s]
Creating json from Arrow format: 100%
                                                                                3/3 [00:00<00:00, 8.97ba/s]
Creating json from Arrow format: 100%
                                                                                3/3 [00:00<00:00, 9.14ba/s]
Creating json from Arrow format: 100%
Saved JSONL splits.
```

```
from transformers import AutoTokenizer, AutoModelForCausalLM
from peft import LoraConfig, get_peft_model
tokenizer = AutoTokenizer.from_pretrained(cfg.model_name, use_fast=True)
if tokenizer.pad_token is None:
    tokenizer.pad_token = tokenizer.eos_token
model = AutoModelForCausalLM.from_pretrained(cfg.model_name)
lora_config = LoraConfig(
    r=16, lora_alpha=32, target_modules=["q_proj","v_proj"],
    lora_dropout=0.05, bias="none", task_type="CAUSAL_LM"
model = get_peft_model(model, lora_config)
model.gradient_checkpointing_enable()
model.config.use_cache = False
model.print trainable parameters()
tokenizer_config.json: 100%
                                                                    685/685 [00:00<00:00, 18.1kB/s]
config.json: 100%
                                                           644/644 [00:00<00:00, 23.7kB/s]
               899k/? [00:00<00:00, 19.4MB/s]
vocab.json:
merges.txt:
               456k/? [00:00<00:00, 18.9MB/s]
special_tokens_map.json: 100%
                                                                       441/441 [00:00<00:00, 52.7kB/s]
pytorch_model.bin: 100%
                                                                 663M/663M [00:13<00:00, 52.6MB/s]
model.safetensors: 100%
                                                                 662M/662M [00:09<00:00, 87.0MB/s]
                                                                     137/137 [00:00<00:00, 3.24kB/s]
generation_config.json: 100%
trainable params: 1,572,864 || all params: 332,769,280 || trainable%: 0.4727
```

```
from datasets import load_dataset
train_ds = load_dataset("json", data_files=cfg.train_path, split="train")
val_ds = load_dataset("json", data_files=cfg.val_path, split="train")
def format_example(example):
    return {"text": example["prompt"] + "\n" + example["response"]}
train_fmt = train_ds.map(format_example, remove_columns=train_ds.column_names)
val_fmt = val_ds.map(format_example, remove_columns=val_ds.column_names)
def tokenize(examples):
    out = tokenizer(examples["text"], truncation=True, max_length=cfg.max_length)
    out["labels"] = out["input_ids"].copy()
    return out
train_tok = train_fmt.map(tokenize, batched=True, remove_columns=train_fmt.column_names)
val_tok = val_fmt.map(tokenize, batched=True, remove_columns=val_fmt.column_names)
                       46800/0 [00:02<00:00, 14031.63 examples/s]
Generating train split:
Generating train split:
                       2601/0 [00:00<00:00, 14684.07 examples/s]
Map: 100%
                                                    46800/46800 [00:08<00:00, 7436.00 examples/s]
Map: 100%
                                                    2601/2601 [00:00<00:00, 8500.61 examples/s]
Map: 100%
                                                    46800/46800 [01:07<00:00, 630.31 examples/s]
Map: 100%
                                                     2601/2601 [00:06<00:00, 381.01 examples/s]
```

```
from \ transformers \ import \ Data Collator For Language Modeling, \ Trainer, \ Training Arguments
data collator = DataCollatorForLanguageModeling(tokenizer=tokenizer, mlm=False)
args = TrainingArguments(
    output_dir=cfg.output_dir,
    learning_rate=cfg.learning_rate,
    per_device_train_batch_size=cfg.per_device_train_batch_size,
    per_device_eval_batch_size=cfg.per_device_eval_batch_size,
    {\tt gradient\_accumulation\_steps=cfg.gradient\_accumulation\_steps,}
    num_train_epochs=cfg.num_train_epochs,
    warmup_ratio=cfg.warmup_ratio,
    logging_steps=cfg.logging_steps,
    save_steps=cfg.save_steps,
    fp16=cfg.fp16,
    report_to="none",
    remove_unused_columns=False
# Ensure model parameters require gradients
for param in model.parameters():
    param.requires_grad = True
trainer = Trainer(
    model=model.
    args=args,
    train_dataset=train_tok,
    eval_dataset=None,
    data_collator=data_collator,
trainer.train()
trainer.save_model(cfg.output_dir)
tokenizer.save_pretrained(cfg.output_dir)
print(" LoRA adapter saved to", cfg.output_dir)
```

08/10/2025, 23:53	AlpaCare_Project.ipynb - Colab

```
[1213/2925 53:05 < 1:15:03, 0.38 it/s, Epoch 0.41/1]
Step
      Training Loss
  50
            2.032900
 100
            2.098900
 150
            2.125400
            2.116300
 200
            2.107300
 250
 300
            2.077100
 350
            2.045400
 400
            2.038100
 450
            1.981400
 500
            1.956300
 550
             1.969700
 600
             1.914500
 650
             1.912800
 700
             1.889000
 750
             1.887400
 800
             1.887200
 850
             1.868500
 900
             1.825300
 950
             1.844400
 1000
             1.809600
 1050
             1.801600
 1100
             1.776000
 1150
             1.776100
1200
             1.760100
                                         [2925/2925 2:07:30, Epoch 1/1]
      Training Loss
Step
  50
            2.032900
 100
            2.098900
            2.125400
 150
            2.116300
 200
            2.107300
 250
            2.077100
 300
 350
            2.045400
 400
            2.038100
             1.981400
 450
 500
             1.956300
 550
             1.969700
 600
             1.914500
import re
import torch
```

```
import re
import torch
from peft import PeftModel
from transformers import AutoModelForCausalLM

# load base + adapters (same as you did)
base = AutoModelForCausalLM.from_pretrained(cfg.model_name)
ft = PeftModel.from_pretrained(base, cfg.output_dir)
ft.eval()

#Safety config
```

```
DISCLAIMER = "\n\n Disclaimer: This is for educational purposes only. Please consult a doctor."
FORBIDDEN = [
    "diagnose", "diagnosis", "prescribe", "prescription",
    "dose", "dosage", "mg", "tablet", "capsule", "antibiotic", "steroid"
EMERGENCY = [
    "heart pain", "chest pain", "can't breathe", "cannot breathe",
    "shortness of breath", "unconscious", "bleeding heavily", "stroke", "seizure"
def is_emergency(text: str) -> bool:
    t = text.lower()
   return any(k in t for k in EMERGENCY)
def safety_filter(text: str) -> bool:
    t = text.lower()
    return any(k in t for k in FORBIDDEN)
# Helper: clean repetition & trim
def clean_text(t: str) -> str:
   # collapse obvious repeated clauses (A A A)
    t = re.sub(r'(?:\b[\w,;:()\'"-]{2,}\b[\t]*){1,}', lambda m: m.group(0), t)
   # remove exact sentence repeats (case-insensitive)
   sentences = re.split(r'(?<=[.!?])\s+', t)</pre>
   seen = set()
   cleaned = []
    for s in sentences:
       s2 = s.strip()
       if not s2:
           continue
        k = s2.lower()
        if k not in seen:
           cleaned.append(s2)
           seen.add(k)
   t = " ".join(cleaned)
   # small tidy-ups
   t = re.sub(r'\s+', ' ', t).strip()
   return t
# Generation with safe defaults
def generate_raw(prompt: str, max_new_tokens: int = 160) -> str:
    inputs = tokenizer(prompt, return_tensors="pt")
   inputs = \{k: v.to(ft.device) for k, v in inputs.items()\}
    gen_kwargs = dict(
        max_new_tokens=max_new_tokens,
        do_sample=True,
        temperature=0.7,
       top p=0.9,
        repetition_penalty=1.2,  # combats loops
        no_repeat_ngram_size=4,
                                  # blocks n-gram repeats
        early_stopping=True,
        eos_token_id=tokenizer.eos_token_id,
        pad token id=tokenizer.pad token id,
   with torch.no_grad():
        out = ft.generate(**inputs, **gen_kwargs)
   text = tokenizer.decode(out[0], skip_special_tokens=True)
    # cut off any prompt echo — keep only what comes after "Response:"
   if "Response:" in text:
        text = text.split("Response:", 1)[1].strip()
   return clean_text(text)
# Final assistant pipeline
def medical_assistant(user_input: str) -> str:
   # 0) emergency triage on INPUT
   if is_emergency(user_input):
        return " This seems urgent. Please call emergency services immediately." + DISCLAIMER
    # 1) block dosage/prescription queries on INPUT too
    if safety_filter(user_input):
        return " This goes beyond my scope (no prescriptions or dosages). Please consult a doctor." + DISCLAIMER
```